To assemble your dresser: First you will assemble the side panels with the top and bottom panels, start with either the left or right side panels (Panel C) and attach to the top panel (Panel A), then attach your bottom panel (Panel B).

Please note that your drawer slides are already installed on your side panels, as well as your drawers. This will also make it easier to know which side "Panels C" belong on.

After you have assembled your basic box frame you will then attach the small dresser back supports.

